



- THIS DRAWING IS NOT FOR CONSTRUCTION. REFERENCE ONLY.
- FILLED UNIT DIMENSIONS VARY SLIGHTLY. ALWAYS CONFIRM INSTALLED SLOPE ANGLE WITH A BATTER BOARD OR OTHER PHYSICAL SLOPE CHECK METHOD.
- ENSURE TYPICAL MINIMUM BAG TO BAG OVERLAP OF 100mm / 4" TO FULLY ENGAGE THE FLEX MSE PLATE.

TYPICAL SLOPE ANGLES AND SETBACKS
SCALE = N.T.S

| No. | DATE | REVISION | BY |
|-----|------|----------|----|
| | | | |
| | | | |
| | | | |

THE PURPOSE OF THIS DRAWING IS FOR PRELIMINARY DESIGN ONLY. THIS DRAWING SHOULD NOT BE USED FOR FINAL DESIGN OR CONSTRUCTION WITHOUT THE CERTIFICATION OF A PROFESSIONAL ENGINEER REGISTERED IN THE REGION IN WHICH THE WALL WILL BE BUILT. THE ACCURACY AND USE OF DETAILS CONTAINED IN THIS DOCUMENT ARE THE SOLE RESPONSIBILITY OF THE USER. THE USER MUST VERIFY EACH DETAIL FOR ACCURACY AS THEY PERTAIN TO THEIR PARTICULAR PROJECT.



PH: 1-877-349-5945
E: INFO@FLEXMSE.COM
WEB: WWW.FLEXMSE.COM

| | |
|-----------------------------------|--------|
| DETAIL | |
| TYPICAL SLOPE ANGLES AND SETBACKS | |
| DATE | |
| SCALE | N.T.S |
| DRAWING NO. | 1 OF 1 |